Receptacle

INSTALLATION INSTRUCTIONS





IMPORTANT: Read ALL instructions before starting installations.


CAUTION: To reduce risk of shock, **TURN OFF ELECTRICAL SUPPLY** before installing/servicing fixtures. **WARNING:** Fixture must be installed in accordance of National Electrical Code (NEC) and /or any local codes.

Failure to do so may result in serious injury and/or damage to the fixture.

SAFETY INSTRUCTIONS

- Verify that supply voltage matches the voltage marked on the fixture label. Failure to do so may result in damage to the light fixture and will void the warranty.
- Observe and follow all label information and instructions regarding dry, damp and wet location listings, proper type and wattage, warnings of installation near combustible materials and or insulation.
- Be sure to connect ground wire to prevent electric shock or other potential hazards.
- Product must be installed in a manner consistent with the intended use and in compliance with national electrical codes and local codes.
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- These instructions do not purport to cover all details or variations of installations, operation or maintenance. Contact Solais Lighting Group if a specific problem or clarification needs to be addressed that is not covered by these instructions.

RECOMMENDED TOOLS




WIRING DIAGRAM



INSTRUCTIONS:

- Photocontrol Receptacle Adjustment
 - Loosen (2) 6-32 screws on receptacle cover.
 - Rotate center of receptacle with screw driver so that the arrow points in the north direction.
 - Refasten receptacle cover with (2) 6-32 flathead screws to 5-6 in-lbs.
 - Install photocell or shorting cap (not supplied).





5017-000013 Rev B